

# PISTOL PM 49



**EN** Operating instruction

# PISTOL PM 49

## PM 49

CO2-Pistol, cal. 4,5 mm (.177) BB,

*This airgun is not a toy. Treat it with the same respect as if you would treat a firearm. Always carefully follow the safety instructions found in this owner's manual and keep this manual in a safe place for further use*

## SAFETY INSTRUCTIONS

*Before using the gun read carefully the following instructions.*

*Buyers and owners must follow the instructions for the safe use of airguns. Keep the safety instructions during the whole period of operation and maintenance.*

*This item is destined for sportful shooting. The item outward similarity with a fire piece is obliged you to take extra safety considerations. Do not brandish or display this airgun in public. Police officers and other people might consider you having a firearm. Always load the item immediately before shooting. Always treat a weapon as if it was loaded and ready to shoot. Safety shooting glasses should always be worn when firing the weapon.*

### Prohibited activities.

- *Always treat the airgun as if it was loaded.*
- *Never aim your airgun at persons or animals.*



# PISTOL PM 49

- *Avoid ricochets. Never fire at smooth, hard surfaces or water.*
- *Do not leave equipment unattended.*
- *The airgun together with its operating instructions may only be handed over to people who have reached the age of 18 (or older) and who are fully familiar with the handling of it.*
- *Modifications or repairs of guns are only to be effected by authorized agencies or by a skilled gunsmith.*
- *Don't use the item in the idle mood (without gas cylinder).*
- *Keep a weapon out of reach of children.*
- *Never transport a loaded gun. Only load your gun when you intend to fire it. For storage remove gas cylinder.*
- *Only use flawless BBs: Never use the following BBs: with edges, both halves not aligned, used, soiled, or deformed. Warranty expires if non recommended BB are used.*
- *Don't operate technically defective items.*
- *Safety shooting glasses should always be worn when firing the gun.*
- *Don't tighten a screw of the gas cylinder (no pressure more than 1kg/cm<sup>2</sup>).*
- *Carefully make sure that your hands do not get in touch with discharged CO<sub>2</sub> gas. This may cause freezing of the skin. Do not expose the CO<sub>2</sub> cylinder to excessive heat and do not store it at temperatures exceeding 50°C.*

# PISTOL PM 49



*It is possible that certain conditions may affect the item, which can impact its proper performance. These conditions include the usage and maintenance the item at temperatures lower than 10°C. Another condition may be when*

## TECHNICAL DATA

Model:	PM 49
Caliber/Ammo:	cal. 4,5 mm (.177) steel BB
Case material :	metal alloy
System:	CO2-Pistol
Projectiles:	Steel BBs
Magazine capacity:	17 BBs
Energy:	< 3,0 Joule
Velocity:	128 m/s
Weight:	650 g

# PISTOL PM 49

## Pistol PM 49

Allen wrench

Instruction



- |   |                  |    |                   |
|---|------------------|----|-------------------|
| 1 | Safety           | 9  | Magazine follower |
| 2 | Magazine         | 10 | Pistol grip cover |
| 3 | Magazine release | 11 | Allen wrench      |
| 4 | Trigger          |    |                   |
| 5 | Gun-hammer       |    |                   |
| 6 | Rear sight       |    |                   |
| 7 | Front sight      |    |                   |
| 8 | Retention screw  |    |                   |

# PISTOL PM 49

## Safety



**OFF SAFE**



**ON SAFE**

## Preparation for use



Put the air pistol “On Safe” (1) and remove the magazine by pressing the magazine release button forward (2) and pulling the magazine from the bottom of the grip frame (3).



Pull down and lock magazine follower (9). Load BBs. Load up to 17 (.177 caliber) steel BBs through the loading port covering with your finger the upper part of the magazine, unlock magazine follower.

# PISTOL PM 49



Pull the pistol grip rearward exposing the CO<sup>2</sup> housing (10).

Unscrew cylinder retention screw using allen wrench (8).



Insert the cylinder.

Tighten cylinder retention screw.



Replace grip cover (10).

Insert the magazine (2).

# PISTOL PM 49

## Aiming pointing




The air pistol is correctly aimed when the front sight blade is positioned exactly in the notch and even with the rear sight. The top of the front sight blade should be even with the top of the notch in the rear sight. The bulls eye should appear to rest on the top of the front sight.

## Shooting

The pistol is ready to fire. When you are sure of your target and backstop, and the area around the target is clear, take the airgun "OFF SAFE" and pull the trigger to fire.

# PISTOL PM 49

A stylized, high-contrast illustration in a comic book style. A man with dark hair, wearing a dark jacket, is shown from the chest up, holding a PM 49 pistol with both hands, pointing it towards the right. The background features a stylized cityscape with a car and a street lamp. The text is overlaid on the lower left of the image.

**Time-proved  
Real Makarov  
Russian character  
Legend of times  
Simply powerful**

# PISTOL PM 49

**Legend Makarov pistol PM 49**  
**Time-proved**  
**Real Makarov**  
**Russian character**  
**Legend of times**  
**Simply powerful**

CBC Inc.  
3259 Davie Blvd.,  
Ft.Lauderdale, Fl.33312  
USA

We reserve the right to make color and design changes and technical improvements. No responsibility is accepted for printing errors or incorrect information.

© Central Bomer Company Inc.